To buy, sell, rent or trade-in this product please click on the link below: https://www.avionteq.com/YED-DATAIR-400-M3-plus-Databus-Tester

AvionTEq

www.avionteq.com



The DATAIR-400/M3+ ARINC 429 handheld Tester provides the user with an easy to use first line diagnostic tool for viewing and generating ARINC 429 data. It allows the user to connect to an ARINC 429 data bus and easily view the active ARINC 429 Labels on the bus or to setup a list of ARINC 429 labels to transmit onto a test data bus in order to simulate a specific test scenario.

The DATAIR-400/M3+ has enhanced features such as ARINC 429 Data Capture, Discrete relay contact for external signalling and assigning an ARINC 429 Label a 0 to 10V output.

Bus Monitor

Connect the receiver to an active ARINC 429 data bus, select the <RECEIVE> menu, press the **ENT** key and the user will be presented with a scrollable list of active ARINC 429 labels. The format of the list of labels can be toggled (by pressing SYM key) between a list of label names and a list of labels with their associated 32-bit values. This provides a very simple monitor involving just a single key press.

Using the \bigwedge keys, select a label of interest from the Bus list and press the ENT key to inspect the data value of the label. This Monitor screen will display in real time the Label number in octal, SSM, SDI, Binary and Hex values, state of Parity, Label transmission rate and the Bus bit rate. If a label has multiple values of SDI then the SDI filter can be scrolled to separate the individual labels. "SDI:XX" is don't care.

By pressing the \mathbf{V} key the user will be presented with a live engineering unit value for this label (if a definition exists). The ARINC 429 decoder circuitry automatically adjusts to 12.5, 50 and 100 k/bps rates.





- An 8 line by 21 character backlit LCD.
- Automatic bus search and bit rate detection 12.5, 50, 100k/bps
- Standard and user definable ARINC 429 definitions
 - User definable engineering units on unit or by external PC SW
- ✓ ARINC 429 definitions selectable by Equipment ID.
- Opto-isolator Rx inputs
- Rechargeable battery providing operation up to 8 hours
- Alphanumeric keypad with menu navigation keys
- VSB Firmware updates Upgrade cable provided
- Standard D15 plug and test leads supplied
- External 5 to 30V DC power input.

ARINC 429 Transmitter

The ARINC 429 transmitter can transmit up to 256 labels at either 12.5, 50 or 100 kbps bit rates. Labels can be transmitted independently of each other at various interval rates between 10mS and 1000mS or in Single Shot mode. The firmware has a built-in data bandwidth checker that prevents any attempt to transmit more labels than the bus can accommodate (ie. ten labels at 12.5kHz at an interval of 10mS will not fit!).

Standard Engineering units

The DATAIR-400/M3+ contains standard ARINC 429 label definitions for transmission and for reception. These definitions are taken from the standard Equipment Identifiers (ID:00A etc.) as defined in the ARINC 429-16 specification. ARINC 429 labels can be selected for transmission by scrolling through the list of labels and "tagging" (shown with an '*') the labels required. Only the Tagged labels will be transmitted.

Custom Engineering units

In addition to the standard label definitions the user has the option to create customer specific labels or modified versions of the standard labels and saving them to non-volatile memory. Custom defined labels override standard label definitions where a duplicate exists. To differentiate between Custom and Standard definitions the Label names of Custom definitions are shown in UPPER CASE whereas Standard labels are shown in lower case. Custom Labels can be created, suspended or deleted. If a label is Suspended or Deleted then the Standard definition becomes active again.

Data Entry for transmitted Labels

Data can be entered in binary or hexadecimal format for any label. If a definition exists for the selected label then an engineering unit value can be entered. Current formats are Binary (BNR) and Binary Coded Decimal (BCD). Special BCD and BNR formats are supported for labels such as L260 (Date), L150 (Time), L011, L010, L310 and L311 (Latitude & Longitude) that have special fields defined within the standard definition. Fields that can be edited within a selected label are the data, SSM and SDI fields. The Parity is automatically created from the entered value and will be set to ODD. However, it is possible to edit the Parity value by writing to Bit-32 directly. Navigation of the screen is by use of the arrow keys.

User Profiles

Transmitter tag lists and data values entered into labels for transmission can be preserved between sessions by saving them to a Profile. Ten Profiles can be saved so that different test scenarios can be easily recalled without the need to set up the instrument each time it is powered on. Profiles can also be created, updated or deleted. Profiles can be backed up to a PC using the PC Label definition and capture download software.

Global settings

Used to configure default states of the instrument to use Metric / Imperial units, transmitted Parity Odd/Even/None and to set the default Inter-Word Gap (IWG) for transmitted labels.

ARINC 429 Data Capture and review

Filter ARINC 429 Labels to capture. Set Start and Stop Triggers by engineering value to capture specific events occurring on the ARINC 429 data bus. After capture:

- View the captured data at the trigger event.
- View data before and after the trigger event.
- View only data that changes in value. This removes static values.
- Search by value (>= or <=), SSM value, Parity error, etc.





Relay output

Assign the internal relay to a discrete bit within a selected ARINC 429 Label. This contact can be made to close on a logic '1' or '0'.

Analogue output

Select an Rx Label with an engineering unit value and assign it to the 0 to 10V output. For example, assign the parameter of Altitude to the output and the zero to full scale value will be converted to a 0 to 10 volt output.

Firmware upgradable and customisation.

The firmware on the DATAIR-400/M3+ can be upgraded by the customer via USB/RS232 link using the supplied cable. This means that features that we have in development can be added at a later date. It also means that if a customer requires the DATAIR-400/M3+ to be customised in a certain way then we can

produce a variant of the firmware specifically for them. There is no requirement to return the instrument to YED for upgrade.

DATAIR-400/M3+ Flite Case

The **DATAIR-400/M3+** instrument and accessories are supplied in a flite case with the following features:

- Quality carry-case with pre-cut foam to hold the main instrument, user manual and all the accessories.
- Spare pockets for additional batteries, custom cables and test leads, etc.
- Rugged exterior and complies with carry-on baggage regulations.

PC Label Definition and Capture download Software

The DATAIR-400/M3+ PC Software is used to create custom ARINC 429 Label definitions and transfer them to the DATAIR-400/M3+. The software is also used to download captured ARINC 429 data on to your PC for export to third party software such as Excel.

The software provides the following features:

- Offline mode for working on local configurations without DATAIR-400/M3+ needing to be present.
- Download and back up any custom defined Labels created on the DATAIR-400/M3+ to your PC.
- Adding/Updating/Deleting custom label storage.
- BNR/BCD and Rx/Tx modifications.
- Download of ARINC 429 data capture file from the DATAIR-400/M3+ to a PC.

The DATAIR-400/M3+ PC software is compatible with Windows XP and higher, x86 and x64, with .NET framework 3.5. No installation is needed, just run it.

Side :	RX •]							Import configuration	Export current configuration
Label	Eq Id (hex)	Type	Param nam	e	Units	Starting bit in msg	Resol in BCD char	Most sig bit reso	Max BCD Value	Decimal point po
141	000	BNR	BODY ROL	L RATE	DEGSEC	0x1D				
067 076	000	BNR	VFOM-2 VFOM		Feet FEET	0x1D 0x1D	al Comm [8]			
Trage in use (0x80) I Label active (0x40) Label : Eq ID : Param name : Unit :				m Softy www	DATAIR-400M3 Serial Communication software version 2.0				•	
141	000	BODY R	OLL RATE	DEGSEC	HID	:				
BCD BNR Number of bits in msg : Scale : 13 ⊕ 128				87B Data FF3	8789-2805-0082-0170-7576 Datair Serial Number : FF3205D300FF9768FFFFFFF SID		Label Editing	Add	Undate	
Numb	er of bits in msg	1	28		30					



Technical Specification

ARINC 429 Receiver				
Input:	Opto-isolator inputs			
Voltage levels (Line A to B):	HI	+6 to 12V		
	NULL	+2.5 to -2.5V		
	LO	-6 to -12V		
Bit rate:	Low Speed:	8 to 18kbps		
	Medium Speed:	45 to 55kbps		
	High Speed:	80 to 125kbps		
ARINC 429 data capture (4 GByte FLASH)				
Maximum capture:	520,000 ARINC 429 words, 9.5 hours @ 100uS			
Data capture triggers:	Start and Stop with pre-trigger buffer.			
Relay output:	220V DC @ 1 Amp. Assign to Label or Trigger			
Analogue output	0 to 10V for BNR / BCD ARINC 429 Label.			
ARINC 429 Transmitter				
Output:	Industry standard line driver			
Output impedance:	75 ±5 Ω (Line A to B)			
Voltage levels (Line A to B):	HI	+10V ±1V		
	NULL	0.0 to ±0.5V		
	LO	-10V ±1V		
Bit rate:	Low Speed:	12.5kbps ±0.5%		
	Medium Speed: 50.	0kbps ±0.5%		
	High Speed:	100.0 kbps ±0.5%		
Word rate:	10 to 1000mS			
Parity:	ODD / EVEN / NONE			
Mass				
Weight:	0.55kg			
Dimensions:	22.9H x 9.7W x 5.4D	CM		
Power requirements				
Input:	5 to 30V DC external power OR			
	4.8V @ 2200mAH Nil	MH detachable battery.		
	Approximately 8 hou	rs of use from full charge		
Low battery indication:	25% early warning le	vel on LCD.		
Environmental				
Operating temperature:	0 to 50 °C (Indoor us	e only)		
Relative Humidity:	0% to 85%			



The information contained in this brochure is subject to change without notice. YED shall not be liable for errors or omissions contained herein.